



Tough Stuff Products, Inc.

Limb Risers

READ ALL OF THE INSTRUCTIONS BEFORE STARTING!

Check our website for any updated instructions! www.toughstuffproducts.com >>
[Jeep® Accessories](#)>>[Limb Risers](#)>>[Installation Instructions](#)

NOTE: Windshield Brackets (P/N 000306) are required to complete this installation.

Tools Required 5/16 inch wrench or socket/ratchet

Instructions Step 1: Install Fender Brackets


Remove 5 each 5/16 inch bolts that secure the front of the plastic fender flares to the fenders. Lay these bolts and the plastic nuts aside.

Repeat on both sides of the Jeep ®.

Pull the plastic flare out and slide the Limb Riser bracket into place as pictured.

Cut the black foam into 2 each 6 inch long pieces. This will fill the small gap between the flare and the fender when the bracket is installed. Place the foam level with the top of the plastic flare in the area marked with arrows in the photo.

Replace the 5 bolts and plastic nuts, sandwiching the bracket in place. Three (3) of the bolts will go through corresponding holes in the fender bracket. Tighten all 5 securely.



Step 2 Install Cable

Attach cable as shown in the following photos. Note that the cable goes DOWNWARD through the top hole and comes UPWARD where it hooks the cable stop.



Run the threaded cable end through the hole in the fender bracket and secure with the wingnut, DO NOT over tighten.

A black nylon tie is also included to attach your radio antenna to the passenger side bracket. Leave the tie loose, so the antenna will not directly touch the metal bracket.

Thank you for purchasing our product, we also manufacture many other body protection and accessory items for your vehicle, our complete product line can be viewed at www.toughstuffproducts.com.