

INSTALLATION INSTRUCTIONS

Universal Security Lockbox #247

Please read and fill out the enclosed warranty registration card to activate your warranty.

PARTS CHECKLIST







#8.2 - 5/16 x 1" BOLT

#8.1 - 5/16 NYLOCK NUT

#8.3 - 5/16" WASHER

TOOLS NEEDED

- Electric drill (Optional)
- 18MM Socket and Ratchet
- ½" Socket and ratchet (Optional)
- 3/16" Allen wrench (Optional)
- Marker or pencil
- Knife

PLEASE READ ALL INSTRUCTIONS THOROUGHLY BEFORE STARTING INSTALLATION.

Warning! Do not operate the vehicle without the drawer locked shut. If left unlocked normal vehicle movements while driving could cause the drawer to open creating an unsafe situation.

Note: To remove the drawer from the enclosure, pull the drawer out as far as it can go then locate the small black plastic stops visible on the ball bearing drawer slides. One of the black stops will need to be deactivated by pressing down and the other one pulled up. Be careful not to break plastic stops. While deactivating the stops push the center slide section back into the drawer enclosure off of the front slide section attached to the drawer until they are separated. To reinstall, line up the slide sections and push the drawer in gently, do not force it or it can be damaged.

- 1. Remove the original seat mounting bolts #8.4 holding the front of the Drivers side seat to the body. (See Figure 1)
- 2. Insert the drawer in the mounted position. Make sure the right side seat bracket #8.6 is under the mounting flange on the Tuffy drawer and the left side seat bracket #8.7 is on top of the mounting flange on the drawer as illustrated. (See Figure 1)

OPTIONAL SECURITY STEP

WARNING! - Make sure that there is nothing under the vehicle that will be damaged by the drill bit when drilling. The exhaust is located in that area, be cautious not to touch it when hot.

For additional security remove the drawer from the enclosure (See note above). Mark the spot in the vehicle floor under the hole in the bottom of the drawer enclosure and drill a 3/8" hole. Fasten using the included bolt #8.2, washer #8.3 and Nut #8.1. It is recommended to use silicone sealant on any drilled holes to prevent rusting. (See Figure 1)

3. Fasten the Tuffy drawer down using the original seat mounting bolts #8.4. (See Figure 1)

Figure 1

Original Seat bolts

8.2

8.4

Tab is on top of seat bracket

Tab is under seat bracket

Call (970)564-1762 for Technical Support